

Compatibility:

The Yealink T46U desk phone supports WiFi, but requires a WF50 USB WiFi Adapter and a telephone power supply (available for purchase from POPP).

The Yealink T54W and T57W desk phones include integrated WiFi capabilities without the need for a WiFi Adapter. A telephone power supply (available for purchase from POPP) is required.

How it Works:

Connecting to WiFi allows the desk phone to connect to the network wirelessly instead of using a wired Ethernet connection.

Getting Started:

Before you can setup WiFi, POPP must enable WiFi on your phone profile. Contact POPP's Helpline at 763-797-7900 prior to completing the steps below.

Yealink Desk Phone WiFi Setup on a T45U or T54W:

1. Plug in the telephone power supply
2. If you're using a T46U phone, also plug in the USB WiFi Adapter into the back of the phone
3. Press the [Menu] softkey
4. Use the navigation keypad to select Basic > Wi-Fi > set Wi-Fi setting to On and press the [Save] softkey
5. Use the navigation keypad to select Easy Connection, then press the [Connect] softkey
6. Press the [Wi-Fi List] softkey
7. Use the navigation keypad to select the desired wireless network, then press the [Connect] softkey
8. Enter the password, making sure to use the [123...abc..] softkey to toggle between numbers, letters, and symbols when entering the password
9. Press the [Connect] softkey
10. Once connected, a check mark will display next to the network

Yealink Desk Phone WiFi Setup on a T57W:

1. Plug in the telephone power supply
2. Touch the [Menu] softkey
3. Touch [Basic] > scroll down and touch [Wi-Fi] > set Wi-Fi setting to [On]
4. View available Wi-Fi networks below
5. Touch to select the desired wireless network
6. Enter the password using the on-screen keyboard and minimize the keyboard when finished
7. Touch the [OK] softkey
8. Once connected, a "connect successfully!" will appear

For Additional Training and Support

- Visit www.popp.com or call POPP Communications at 763-797-7900