



Make Internal Call:

- Dial [4-digit extension] and press [Start Call] button

Make External Call:

- Dial [10-digit phone number] and press [Start Call] button

Redial Last Internal or External Number Dialed:

- Press [Start Call] button to access the redial list
- Press [▲] or [▼] to select the desired entry and press [Start Call]

Adjust Volume:

- Speaker Volume: Press the [▶] navigation button to increase the volume. Press the [◀] navigation button to decrease the volume.
- Ring Volume: While telephone is idle, press the [▶] navigation button to increase the volume. Press the [◀] navigation button to decrease the volume.

Silence Ringer:

- Press the [◀] navigation button to decrease the volume until the display indicates **Ring Volume is Off**. The **ringer off** icon will appear on the display.
- Press the [▶] navigation button to increase the volume and enable ringing. The **ringer off** icon will disappear from the display.

Mute Calls:

- Press the [Mute] button. The **mute** icon will appear at the top of the display. Press the [Mute] button again to unmute the call. The **mute** icon will disappear from the top of the display.

Holding Calls:

- Press the [Options] softkey. Press the [▼] navigation button to select **Hold**. Press the center [OK] button to place the call on hold. The **Hold** message will appear on the display.
- To pick up call on hold, press the [Resume] softkey. The **Hold** message will disappear from the display.

Pick Up a Call Ringing at Another Extension:

- Dial [*12] + [4-digit extension] and press the [Start Call] button

Note: Paging is not available on the Yealink W56H Cordless Phone.

Transfer Call:

- Press the [Options] softkey. Press the center [OK] button to select **Transfer**.
- Dial the [4-digit extension] to which you would like to transfer the call, wait for the person to whom you are transferring the call to answer, and announce the call
- Press the [Transfer] softkey to complete the transfer.

Send Caller Directly to Your Voicemail:

- While telephone is ringing, press [End Call] button. **Note:** Your Call Forward No Answer number must be set to voicemail.

Transfer Call Directly to Another User's Voicemail:

- Press the [Options] softkey
- Press the [OK] softkey to select **Transfer**
- Dial the [*76] + [4-digit extension]
- Press the [Transfer] softkey to complete the transfer
- A **Call Transferred** message will appear on the display

Make Conference Call (3 party max.):

- With first caller on the line, press the [Options] softkey. Press the [▼] navigation button to select **Conference**. Press the center [OK] button.
- Dial next party [4-digit extension or 10-digit phone number]
- When answered, press the [Conf] softkey to join all parties. When you hang up, the conference call is ended for all parties.

Park Call:

- With caller on the line, press the [Options] softkey. Press the center [OK] button to select **Transfer**.
- Dial [*13]. You will hear, "Your call will be parked on orbit 1XX."
- Press the [Transfer] softkey to complete the transfer and park the call. Note the orbit number the call is parked on.

Pick Up Call on Park:

- Dial [*14] + [orbit number] of the parked call and press the [Start Call] button to retrieve the call

View Call History:

- Press the [History] softkey to display the **Call History**. Or you may press the center [OK] button, select **History**, and press the center [OK] button again.
- Press [▲ or ▼] navigation button to scroll through the list of calls
- Press the [Start Call] button to call the phone number, or the [Back] softkey to go **Back**.

For Additional Training and Support

- Visit www.popp.com or call POPP Communications at 763-797-7900