

Background:

Follow the procedure below to pair a Yealink W56H handset to a base station.

Procedure:

1. Before registering the handset:
 - a. Connect the cordless phone base to an ethernet jack in order to establish a network connection.
 - b. Plug the power adapter for the handset charging cradle into an outlet and charge the handset.
2. On the cordless phone base, press and hold this button (1) until the LED shown (2) begins to flash:



3. On the handset, press the softkey that says **Reg**. This will search for the base (so be reasonably close by). The handset should pair automatically.
4. If you are prompted for a Base Station PIN, enter **7677** (default from POPP) or **0000** (default from factory).



For Additional Training and Support

- Visit www.popp.com or call POPP Communications at 763-797-7900