

Compatibility:


The USB WiFi Adapter is compatible with Poly VVX phone models with a USB port. A phone power supply and firmware version 5.8 or higher are also required. Note: VVX 250, 350, and 450 phone models cannot use a USB headset when a USB WiFi Adapter is in use.

How it Works:

The USB WiFi Adapter allows Poly phones to connect to the network wirelessly instead of using a wired Ethernet connection.

Setup:

- Insert the USB WiFi Adapter into a USB port on your Poly VVX phone
- The phone screen will display a prompt "A WiFi adapter is connected. Press Start to begin Wi-Fi setup"
- Press **[Start]** softkey
- Select **Wi-Fi**, then select **ON**.
- Press **[yes]** softkey when the phone screen displays, "Do you want to continue". The phone will reboot.



- After the phone has rebooted, press the **Home** button and navigate to **Settings** → **Basic** → **Wi-Fi** to continue the WiFi set up
- The phone will automatically scan for WiFi networks. If the phone does not automatically scan, press **[Scan]** softkey to initiate a scan. If a WiFi network is saved in the phone, the phone will try to connect automatically.
- Press **[Select]** softkey to select a network in the list
- Use the dial pad to enter the network password:
 - Press **[Encoding]** or **[Mode]** softkey to switch between Abc, ABC, abc, or 123 for Title case, UPPERCASE, lowercase, or numerical entries
 - To enter special characters, Abc, ABC, or abc must be selected along with ASCII. Press the 1, 0, *, or # key to access the following characters:
 - **[1] key:** ! | ' ^ \ @ : 1
 - **[*] key:** * - & % + ; ()
 - **[0] key:** / , _ \$ ~ = ? 0
 - **[#] key:** # > < { } [] " ' `
 - To delete characters, press the **[<<]** softkey
- Press **[More]** softkey followed by **[Connect]** softkey and phone will connect. Once connected, the phone screen will display a "Connected" message.

For Additional Training and Support

- Visit www.popp.com or call POPP Communications at 763-797-7900