





1



2




3



4

VVX 450 FRONT OF PHONE

- Voicemail indicator light



5

VVX 450 FRONT OF PHONE

- Programmable keys



6



VVX 450 FRONT OF PHONE

- Home key



7



VVX 450 FRONT OF PHONE

- Softkeys



8

VVX 450 FRONT OF PHONE


- Navigation buttons



9

VVX 450 FRONT OF PHONE

- Headset and Speaker buttons



10



VVX 450 FRONT OF PHONE

- Mute




11



VVX 450 FRONT OF PHONE

- Volume



12



VVX 450 FRONT OF PHONE

- Transfer




13



VVX 450 FRONT OF PHONE

- Voicemail



14



VVX 450 FRONT OF PHONE

- Hold




15



VVX 450 FRONT OF PHONE

- Standard 12-button keypad



16



VVX 450 FRONT OF PHONE

- Direct Inward Dial (DID) Number



17



VVX 450 FRONT OF PHONE


For more training videos, visit
www.popp.com/support



18



19



20

VVX 350/450 DIALING OUTBOUND

- Use the backspace softkey to correct a misdiald number



21

VVX 350/450 DIALING OUTBOUND

- Pick up the handset or press Dial
- You may also use a headset



22



VVX 350/450 DIALING OUTBOUND

For more training videos, visit
www.popp.com/support



23



POLY VVX 350/450

DIALING TOLL FREE OR LONG DISTANCE

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

24



VVX 350/450 DIALING TOLL FREE OR LONG DISTANCE

- Entering a 1 is not required




25



VVX 350/450 DIALING TOLL FREE OR LONG DISTANCE

- Enter the 10-digit toll free or long distance number



26



VVX 350/450 DIALING TOLL FREE OR LONG DISTANCE

For more training videos, visit
www.popp.com/support



27



POLY VVX 350/450

RECEIVING AN INBOUND CALL


THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

28



VVX 350/450 RECEIVING AN INBOUND CALL

- Answer, Reject or Ignore the call



29



VVX 350/450 RECEIVING AN INBOUND CALL

- To answer the call:
 - Pick up the handset
 - Press the speakerphone button
 - Press the Answer softkey (defaults to speakerphone)



30



VVX 350/450 RECEIVING AN INBOUND CALL

- To send a call directly to voice mail, press the Reject softkey



31



VVX 350/450 RECEIVING AN INBOUND CALL

- To silence the ringer, press Ignore



32



VVX 350/450 RECEIVING AN INBOUND CALL

For more training videos, visit
www.popp.com/support



33



POLY VVX 350/450

RECEIVING A SECOND INBOUND CALL


THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

34



VVX 350/450 RECEIVING A SECOND INBOUND CALL

- Answer, Reject or Ignore the call



35



VVX 350/450 RECEIVING A SECOND INBOUND CALL

- To answer the call, press the Answer softkey




36



VVX 350/450 RECEIVING A SECOND INBOUND CALL

- Your first caller will automatically be placed on hold




37



VVX 350/450 RECEIVING A SECOND INBOUND CALL

- To return to your first caller:
 - Use Navigation Keypad to select the held call




38



VVX 350/450 RECEIVING A SECOND INBOUND CALL

- To return to your first caller:
 - Use Navigation Keypad to select the held call
 - Press the Resume softkey
- The second caller is placed on hold
- A headset can also be used



39



VVX 350/450 RECEIVING A SECOND INBOUND CALL

For more training videos, visit
www.popp.com/support



40