




1



2

POPP
www.popp.com

POLY VVX 350/450

ACCESS VOICE MAIL

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.


3

POPP
www.popp.com

VVX 350/450

ACCESS VOICE MAIL

- To access your voice mail from your desk phone:
 - Press the Envelope or Cassette button



4



VVX 350/450 ACCESS VOICE MAIL

- To access your voice mail from your desk phone:
 - Press the Envelope or Cassette button
 - Enter your PIN followed by pound (#)




5



VVX 350/450 ACCESS VOICE MAIL

- To access your voice mail remotely:
 - Call your Direct Dial (DID) number
 - Dial star (*) when your greeting plays
 - Enter your PIN (from POPP), followed by pound (#)



6



VVX 350/450 ACCESS VOICE MAIL

For more training videos, visit
www.popp.com/support



7



POLY VVX 350/450

RECORD VOICE MAIL GREETING

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

8



VVX 350/450 RECORD VOICE MAIL GREETING

- To record or change your voice mail greeting:
 - Log in to voice mail
 - Follow prompts and press [3], [1], [1]



9



VVX 350/450 RECORD VOICE MAIL GREETING

- After listening to the prompts:
 - Press [1] to re-record your greeting
 - Record your personal greeting
 - Press [#]
 - Press [1] to save



10



VVX 350/450 RECORD VOICE MAIL GREETING

For more training videos, visit
www.popp.com/support



11



POLY VVX 350/450

RECORD VOICE MAIL NAME

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

12



VVX 350/450 RECORD VOICE MAIL NAME

- To record your name, from the main menu:
 - Press [3], [3], [2], [1]
 - Record your name
 - Press [#]
 - Press [1] to save



13



VVX 350/450 RECORD VOICE MAIL NAME

For more training videos, visit
www.popp.com/support



14




POLY VVX 350/450

CHANGE VOICE MAIL PIN

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

15




VVX 350/450

CHANGE VOICE MAIL PIN

- To change your PIN, from the main menu:
 - Press [4], [3], [1]
 - Enter your new PIN (4-20 digits)
 - Press [#]

Note: Your PIN cannot contain a sequence, a single digit repeated more than twice, or any part of the mailbox number



16



VVX 350/450 CHANGE VOICE MAIL PIN

For more training videos, visit
www.popp.com/support



17



POLY VVX 350/450

VOICE MAIL INDICATOR

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

18

VVX 350/450 VOICE MAIL INDICATOR

- When a voice mail is left in your voice mail box:
 - The voice mail indicator light will flash
 - The phone will display an icon next to your DID
 - The number of messages will display



19

VVX 350/450 VOICE MAIL INDICATOR

For more training videos, visit
www.popp.com/support



20




www.popp.com

POLY VVX 350/450

CHECK VOICE MAIL MESSAGES

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

21




www.popp.com

VVX 350/450

CHECK VOICE MAIL MESSAGES

- To check your messages:
 - Press the Envelope or Cassette button
 - Enter your PIN
 - Press [#]



22



VVX 350/450 CHECK VOICE MAIL MESSAGES

- Once logged in:
 - Press [1] to retrieve messages
 - Listen to message
 - Follow prompts for message handling options



23



VVX 350/450 CHECK VOICE MAIL MESSAGES

- Common message handling options are:
 - Press [1] to replay
 - Press [2] to save
 - Press [3] to delete
 - For more options, refer to the voice mail user guide found at www.popp.com/support



24



VVX 350/450 CHECK VOICE MAIL MESSAGES

For more training videos, visit
www.popp.com/support

