



POLY VVX 350/450

VOLUME, AUDIO, AND RINGTONE SETTINGS - INTRODUCTION

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

1




VVX 350/450
VOLUME, AUDIO, AND RINGTONE SETTINGS
- INTRODUCTION



2



3



4



VVX 350/450 HANDSET VOLUME

For more training videos, visit
www.popp.com/support



5

POLY VVX 350/450

SPEAKER VOLUME

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

6

VVX 350/450 SPEAKER VOLUME

- To adjust the speaker volume:
 - Press the Speaker button



7

VVX 350/450 SPEAKER VOLUME

- To adjust the speaker volume:
 - Press the Speaker button
 - Press or hold the plus (+) or minus (-) on the volume button
- This adjustment can also be made during a phone call while using the speakerphone



8

VVX 350/450 SPEAKER VOLUME

For more training videos, visit
www.popp.com/support



9



POLY VVX 350/450

HEADSET VOLUME

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

10

VVX 350/450 HEADSET VOLUME

- To adjust the headset volume:
 - Press the Headset button



11

VVX 350/450 HEADSET VOLUME

- To adjust the headset volume:
 - Press the Headset button
 - Press or hold the plus (+) or minus (-) on the volume button
- This adjustment can also be made during a phone call while using a headset



12



VVX 350/450 HEADSET VOLUME

For more training videos, visit
www.popp.com/support



13



POLY VVX 350/450

MUTE OUTBOUND AUDIO

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

14



VVX 350/450 MUTE OUTBOUND AUDIO

- To mute outbound audio:
 - Press the Mute button



15



VVX 350/450 MUTE OUTBOUND AUDIO

- To unmute:
 - Press the Mute button again



16



VVX 350/450 MUTE OUTBOUND AUDIO

For more training videos, visit
www.popp.com/support



17



POLY VVX 350/450

RING VOLUME

THIS VIDEO FEATURES A VVX 450. BUTTON LOCATIONS MAY VARY SLIGHTLY ON DIFFERENT PHONE MODELS.

18



VVX 350/450 RING VOLUME

- To adjust the ring volume (with the phone idle):
 - Press or hold the plus (+) or minus (-) on the Volume button
 - The sample ring tone will indicate the new ring volume



19



VVX 350/450 RING VOLUME


For more training videos, visit
www.popp.com/support



20



21



22

VVX 350/450 CHANGE EXTERNAL RINGTONE

- Use the navigation keypad to select:


- Settings
- Basic
- Ring Type
- Default



23

VVX 350/450 CHANGE EXTERNAL RINGTONE


- The Play softkey can be used to sample each ring tone



24

VVX 350/450 CHANGE EXTERNAL RINGTONE


- Use the Select softkey to select the desired ringtone



25

VVX 350/450 CHANGE EXTERNAL RINGTONE

- Lift the handset and hang up to exit the menu



26



VVX 350/450 CHANGE EXTERNAL RINGTONE

For more training videos, visit
www.popp.com/support

