







YEALINK DESKPHONE BLUETOOTH - INTRODUCTION

- T46U phone model - **requires BT41 USB Bluetooth Adapter (available for purchase from POPP)**
- T54W phone model - built-in Bluetooth








YEALINK DESKPHONE ENABLING BLUETOOTH



- T46U model only – plug BT41 Bluetooth Adapter into a USB port on the back of the phone





YEALINK DESKPHONE ENABLING BLUETOOTH


- Press the [Menu] softkey
- Navigate to the Basic menu option
- Press [OK] button





YEALINK DESKPHONE ENABLING BLUETOOTH



- Scroll down to select Bluetooth
- Press [OK] button





YEALINK DESKPHONE ENABLING BLUETOOTH


- Press the [Switch] softkey to turn Bluetooth On
- Press the [Save] softkey





YEALINK DESKPHONE ENABLING BLUETOOTH


- Turn on your Bluetooth headset and put it into pairing mode (see headset manual for instructions)
- Press the [Scan] softkey





YEALINK DESKPHONE ENABLING BLUETOOTH


- Your Bluetooth headset will appear on the screen once detected
- Press the [Connect] softkey





YEALINK DESKPHONE ENABLING BLUETOOTH

- A message will display once your headset is connected
- Your Bluetooth headset is now paired to the phone





YEALINK DESKPHONE ENABLING BLUETOOTH

For more training videos, visit
www.popp.com/support





POPP
www.popp.com

YEALINK DESKPHONE

USING A BLUETOOTH HEADSET

NOTE: THE PROCESS FOR USING A BLUETOOTH HEADSET VARIES BY MANUFACTURER. THIS VIDEO FEATURES A T54W. PROCEDURE MAY VARY ON SOME MODELS.



YEALINK DESKPHONE USING A BLUETOOTH HEADSET

- Incoming calls will alert the Bluetooth headset and ring your deskphone
- To answer a call:
 - Press the [Headset] button on the phone
 - Or press the button on the Bluetooth headset





YEALINK DESKPHONE USING A BLUETOOTH HEADSET

To move a call from the deskphone to the Bluetooth headset:

- Press the [Headset] button on the phone
- Or press the button on the Bluetooth headset





YEALINK DESKPHONE USING A BLUETOOTH HEADSET




- To end a call:
 - Press the [End Call] softkey on the phone
 - Or press the button on the Bluetooth headset





YEALINK DESKPHONE USING A BLUETOOTH HEADSET


- To page from the Bluetooth headset:
 - Press the [Paging] key on the phone
 - Select the Page Group





YEALINK DESKPHONE USING A BLUETOOTH HEADSET

- Press the [Paging] softkey on the phone to initiate the page






YEALINK DESKPHONE USING A BLUETOOTH HEADSET

- Press the [End Call] softkey when finished

Note: Paging key must be programmed by POPP. Pages using a Bluetooth headset may not sound as loud or clear as pages from the phone.





YEALINK DESKPHONE USING A BLUETOOTH HEADSET

- To adjust the call volume while on a call:
 - Press the [Volume] buttons on the phone
 - Or press the volume buttons on the headset
 - Volume changes save automatically
- The Bluetooth headset alert volume is adjusted using the headset volume buttons while a call is alerting





YEALINK DESKPHONE USING A BLUETOOTH HEADSET

- To mute a call:
 - Press the [Mute] button on the phone
- Additional features may be available (see headset user guide)





YEALINK DESKPHONE USING A BLUETOOTH HEADSET

For more training videos, visit
www.popp.com/support

